


## ABDOMINAL WOUND DRESSING



01.

Remove plastic barrier if not required.




04.

Reverse direction of bandaging and wrap elastic bandage to cover the bottom half of the pad.




02.

Place pad on wound area (do not press down).




05.

A. Proceed to wrap around torso.  
B. Be sure to cover all edges of the pad



03.

A. Wrap elastic bandage around torso & bring to front of body (do not tighten).  
B. Wrap elastic bandage to cover the top half of the pad, insert into pressure applicator.



06.

A. Secure wrapping leader by hooking the closure bar into previous layers of the wrapping leader.  
B. Thoroughly wet bandage pad to keep wound area moist.